

# Industrial Gauge and Duratemp® Pointer Options

## Pointer Options

**XSH - Stationary Red Set Hand (On Dial)**

**XEO - External Adjustable Red Set Hand with Knob (On Window)**



**1009**  
2½" dial with back flange



**C-600A-03**



**1009**  
4½" dial

**Model/Dial Size**

1008	Sizes 63 and 100mm
1009	Sizes 2½", 3½", 4½" and 6"
2008	Size 63mm
C-600A/600B/600H	Sizes 4½", 6", 8½"

Note: XSJ Dual Stationary Pointers is valid for 1008, 1009 and 2008 listed above

**Model/Dial Size**

1009	Sizes 4½" and 6"
C-600A/600B/600H	Sizes 4½" and 6"
N/A with liquid fill units	

**XEO - External Adjustable Red Set Hand (On Window)**

**XEP - External Adjustable Pointer (Min./Max.)**



**1009**  
2½" dial



**1009**  
4½" dial



**C-600A-01**

**Model/Dial Size**

1009	Sizes 2½" and 3½"
------	-------------------

Note: N/A with liquid fill units

**Model/Dial Size**

1009	Sizes 4½" and 6"
C-600A/600B/600H	Sizes 4½" and 6"

N/A with liquid fill units

# Industrial Gauge and Duratemp<sup>®</sup> Pointer Options

## Pointer Options

XED, XEE, XEF, XEG - Electric Contacts



C-600A-02

### Model/Dial Size

C-600A-02	Sizes 4½" and 6"
C-600A-03	
C-600A-04	

### Options

ED	High and Low
EE	Double High
EF	Double Low
EG	Low and High